DL立式多级离心泵
JDL4-12.5-U1U1V-I内装机封更换作业
DL series vertical multistage
centrifugal pump JDL4-12.5-U1U1V-I
replacement inside mechanical seal

拆解电机座两侧防护罩
Dismantle the motor stool protective
plates on both sides.

拆除联轴器螺栓
Dismantle the coupling bolts.

拆除电机座上端螺栓
Dismantle the motor stool bolts.

DL SERIES
MARINE VERTICAL
MULTISTAGE
CENTRIFUGAL PUMP
移走电机
Remove the motor.

DL SERIES
MARINE VERTICAL
MULTISTAGE
CENTRIFUGAL PUMP
拆除放气丝堵
Dismantle the vent plug

DL SERIES
MARINE VERTICAL
MULTISTAGE
CENTRIFUGAL PUMP
拆除拉杆螺母
Dismantle the pull rod nuts

移走电机座
Remove the motor stool.

DL SERIES
MARINE VERTI
MULTISTAGE
CENTRIFUGAL
Nominal diameter
Pressure
Pumped liquid
Frequency
Certification approved
拆除泵盖
Dismantle the pump caver

DL SERIES
MARINE VERTI
MULTISTAGE
CENTRIFUGAL
Nominal diameter
Pressure
Pumped liquid
Frequency
Certification approved
拆除机械密封
Dismantle the mechanical seal

DL SERIES
MARINE VERTI
MULTISTAGE
CENTRIFUGAL
Nominal diameter
Pressure
Pumped liquid
Frequency
Certification approved
新机械密封安装前，请使用润滑脂对O型圈
进行润滑
When install the new mechanical seal
before,please use the lubrication oil to
rubber O ring

DL SERIES
MARINE VERTI
MULTISTAGE
CENTRIFUGAL
Nominal diameter
Pressure
Pumped liquid
Frequency
Certification approved
清洁泵轴
Clean the shaft

拆除机械密封静环
Dismantle the mechanical seal static friction pair

DL SERIES
MARINE VERTI
MULTISTAGE
CENTRIFUGAL
Nominal diameter
Pressure
Pumped liquid
Frequency
Certification approved
对机械密封静环密封垫进行润滑
Use the lubricating oil to the mechanical seal static friction pair

DL SERIES
MARINE VERTI
MULTISTAGE
CENTRIFUGAL
Nominal diameter
Pressure
Pumped liquid
Frequency
安装机械密封静环
(保持摩擦副镜面清洁)
Keep the static friction pair clean.

Nominal diameter
Pressure
Pumped liquid
Frequency
Certification approved
安装泵盖
Install the pump cover

安装电机座
Install the motor stool.

DL SERIES
MARINE VERTICAL
MULTISTAGE
CENTRIFUGAL PUMP
安装放气丝堵
Install the vent plug

DL SERIES
MARINE VERTICAL
MULTISTAGE
CENTRIFUGAL PUMP
安装电机
Install the motor.

DL SERIES
MARINE VERT
MULTISTAGE
CENTRIFUGAL
Nominal diameter
Pressure
Pumped liquid
Frequency
Certification approved
安装联轴器
Install the coupling.

DL SERIES
MARINE VERT
MULTISTAGE
CENTRIFUGAL
Nominal diameter
Pressure
Pumped liquid
Frequency
Certification approved
确保有1-2毫米轴向位移间隙
(参见联轴器作业指导书)
Ensure the shaft have 1-2mm free
axial displacement clearnce
See the"operation mstruction for
coupling adjustment"

DL SERIES
MARINE VERT
MULTISTAGE
CENTRIFUGAL
Nominal diameter
Pressure
Pumped liquid
Frequency
Certification approved
联轴器两侧缝隙一致
Ensure the clearance of coupling
block is consistent.

DL SERIES
MARINE VERT
MULTISTAGE
CENTRIFUGAL
Nominal diameter
Pressure
Pumped liquid
Frequency
Certification approved
安装防护罩
Install protective plates.

DL SERIES
MARINE VERT
MULTISTAGE
CENTRIFUGAL
Nominal diameter
Pressure
Pumped liquid
Frequency
Certification approved
更换作业完成
It's done.